HOME DECORATORS COLLECTION

Item #000-000
Model # 7226

USE AND CARE GUIDE

LED MERCURY GLASS MINI PENDANT LIGHT



Questions, problems, missing parts? Before returning to the store,
call Home Decorators Collection Customer Service
8 a.m. - 6 p.m., EST, Monday-Friday

1-877-527-0313

HOMEDEPOT.COM

THANK YOU

We appreciate the trust and confidence you have placed in Home Decorators Collection through the purchase of this LED Mercury Glass Mini Pendant Light

We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Home Decorators Collection!

Table of Contents

Table of Contents 2
Safety Information 2
Warranty 2
What is Covered 2
What is Not Covered 2
Pre-installation 3
Planning Installation 3
Tools required 3
Hardware Included 3
Package Contents 4
Installation – 5-6
Maintenance 7
Care and Cleaning 7
Troubleshooting 7
Service Parts 8
Model Type 8

Safety Information

IMPORTANT

1. Make sure power is turned off to light fixture prior to installation
2. Installation must be performed by a qualified or licensed electrician
3. To prevent electric shock, do not insert any objects through openings
4. Use safety precautions. Always handle glass lamp base carefully

DANGER: Before installation, turn off the main power at the circuit breaker

CAUTION: To prevent electric shock, do not insert any objects through openings or attempt to open the LED base

WARNING: Installation must be performed by a qualified licensed electrician

Warranty

LIMITED 3 YEAR WARRANTY

WHAT IS COVERED

We warrant this lighting fixture to be free of manufacturing defects to the original purchaser for three years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact the Customer Service Team at 1-877-527-0313 or visit www. HomeDepot.com.

Pre-installation

PLANNING INSTALLATION

Carefully unpack light fixture from box and check contents.

> **WARNING:** Turn off power to fixture prior to installation

TOOLS REQUIRED

Wire Stripper Cutter

Safety goggles



Phillips & Flat head screwdrivers

Electrical Tape

HARDWARE INCLUDED

> **NOTE:** Hardware not shown to actual size.



AA -LED Lamp Holder Decorative Assembly

BB- Lamp Holder Nut

HH- LED Driver

FF - Fixture Mounting Screws (2)



CC- Glass Globe

DD- Ceiling Mounting Bracket

EE - Ceiling Mounting Screws (2)

GG - Wire Nuts (3)

Part	Description	Quantity
AA	LED Lamp Holder Assembly	1
BB	Lamp Holder Nut	1
CC	Glass Globe	1
DD	Ceiling Mounting Bracket	1
EE	Ceiling Mounting Screws	2
FF	Fixture Mounting Screws	2
GG	Wire Nuts	3
HH	LED Driver	1

Pre-installation (continued)

PACKAGE CONTENTS



Part	Description	Quantity
A	LED Lamp Holder Assembly	1
B	Lamp Holder Nut	1
C	Glass Globe	1
D	Ceiling Mounting Bracket	1
E	Ceiling Mounting Screws	2
F	Fixture Mounting Screws	2
G	Wire Nuts	3
H	LED Driver	1

Installation

1 Remove existing light fixture

- □ Remove existing light fixture.
- □ Screw in light mounting bracket.

WARNING: Turn off power to fixture prior to installation



2 Install new fixture - Wiring

- □ Connect wires from light to supply ceiling box wires.
- □ **DO NOT** assemble Glass Globe to fixture assembly yet.

WARNING: Turn off power to fixture prior to installation



Installation (continued)

3 Install new fixture - Wiring

- ☐ For extra safety – use electrical tape over wire nuts and wire.
- ☐ Carefully tuck wires into ceiling electrical box.

WARNING: Turn off power to fixture prior to installation



4 Attaching new fixture to ceiling

- ☐ Place light fixture pan base over mounting bracket.
- ☐ Insert fixture pan screws and tighten to secure light pan.



5 Attach Glass Globe



Maintenance

- To clean the inside of the fixture, first disconnect power to the fixture by turning off the circuit breaker or by removing the fuse at the fuse box.

Care and Cleaning

- To clean the outside of the fixture, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the glass and surface of the fixture.
- Next, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the inside glass and interior surface of the fixture.
- Do not use any cleaners with chemicals, solvents or harsh abrasives. Use only a dry soft cloth to dust or wipe carefully.

Troubleshooting

Problem	Solution
Light will not turn on.	Make sure power supply is on. Test or replace switch. Check wiring.
Fuse blows or circuit breaker trips when light is turned on.	Check wire connections.

Service Parts

MODEL TYPE - 7226



Part	Description	Quantity
A	LED Lamp Holder Assembly	1
B	Lamp Holder Nut	1
C	Glass Globe	1
D	Ceiling Mounting Bracket	1
E	Ceiling Mounting Screws	2
F	Fixture Mounting Screws	2
G	Wire Nuts	3
H	LED Driver	1

HOME
DECORATORS
COLLECTION

Questions, problems, missing parts? Before returning to the store,
call Home Decorators Collection Customer Service
8 a.m. - 6 p.m., EST, Monday-Friday

1-877-527-0313

HOMEDEPOT.COM

Retain this manual for future use.